

Update Log

#	DATE	Assembly plan	REMARK
1	11/12/2012	Tropic Flyscreen	nieuw plan afgewerkt
2	10/04/2013	Alle tropics	Rubber lijst aangepast
3	11/04/2013	Euro-Skandi	nieuw plan afgewerkt
4	14/06/2013	Pyra 3,09 + 3,80	Rubber lijst aangepast + profile explanation list
5	17/09/2013	Muurserre-Vrijstaand	nieuw plan afgewerkt
6	18/09/2013	Maxi	Profile list added + Youtube + assembly + qr code added +strengthening bars roof changed + uitleg verlengingen toegevoegd + rubber aanduiding zoals Euro-Skandi
7	1/10/2013	T-classic	Funderings maten gewijzigd
8	1/10/2013	Tropic Maxi	L 20/15 gedraait
9	25/10/2013	Euro-Maxi	Url Youtube aangepast
10	25/10/2013	Euro-Plusser	Profile list toegevoegd , youtube link , qr code toegevoegd + rubber lijst aangepast .
11	5/11/2013	Euro-Exotic	Url Youtube + montageplan + profile list + QR code + verlengingen + rubber aangeduid
12	6/11/2013	Plusser - on wall	URL montage plan + muur 63 cm toegevoegd + profile list + verlengingen + rubber aanduiding
13	13/12/2013	Gothic	Url assembly plan + wall 63 cm + profile list + 2 piece connections + rubber view + where to drill wallplate + special screw + Strengthening bars corrected + strenghtening U's + Profile list
14	10/01/2014	Gothic-Plusser	Complete new assembly instruction
15	10/01/2014	Plusser	Detail goot + nok 2 stukken aangepast en speciale schroef aanduiden
16	10/01/2014	Euro-Maxi	Speciale schroef aanduiding toegevoegd
17	13/01/2014	Exotic	Speciale schroef aanduiding toegevoegd
18	13/01/2014	Euro-Midi	Speciale schroef aanduiding toegevoegd + goot en nok in 2 delen + Profiel lijst + rubber aanduiding
19	28/01/2014	Euro-Muurserre	Profile list + Left and right corner + Gutter + foundation in 2 pieces + speciale screw + L 40 later
20	31/01/2014	Euro-Starr	Profile List + Foundation and gutter 2 pieces + speciale screw + rubber list
21	7/02/2014	Euro-super	Profile List + Foundation and gutter 2 pieces + speciale screw + rubber list
22		Maxi On wall	Profile List + Where to drill walplate + Wallheights added + Removed Gothic from page 3 + Ridge + Gutter 2 pieces + Rubber list + speciale screw
23	27/08/2014	Veranda	Rubberlijst adjusted + strenghtening bars removed
24	28/01/2015	Maxi	Divided into Maxi 2,36 and Maxi 3,09
25	18/03/2015	Gothic	Divided into 2,36 and 3,09 + Single and double turning door instructions Marking when to have and use U's in the roof
26	21/03/2015	Pyra-stretched	Rubber list + profile list + special screw + side window follow order
27	17/04/2015	Single & Double Paw	New assembly plan created
28	17/04/2015	Side window	New assembly plan created
28	2/06/2015	Divider	New assembly plan created
29	9/06/2015	Euro-Plusser	5,30 width added
30	29/06/2015	Euro-Muurserre	ridge notation adapted
31	13/08/2015	Double Door Pyra	New assembly plan created
32	21/08/2015	Tropic Veranda	profile list + rubber list + L profile door
33	24/08/2015	T-classic	profile list + rubber list
34	25/08/2015	Euro-Veranda	Profile list + gutter in 2 pieces + cut profile roof
35	25/09/2015	Euro-Plusser	Dimension adaptation of the foundation measuraments

36	28/09/2015	Tropic Maxi	Gutter , ridge and foundation in 2 pieces , profile list , rubber list , special screw
37	6/01/2016	Euro-Plusser	Marking updated page 20
38	7/01/2016	Euro-Skandi	Special screw + detail K30/40 + glas bar detail + angle of U 20/40 + Rubber list
39			
40			
41			
42			
43			
44			
45			
46			
47			